QtQuick Training Course



Module Qt Components



Module Qt Components

Objectives

1 Qt Components

What is Qt Components?

Setting up your environment

Basic interface elements

Style

Text input

Buttons

Menu

Dialog boxes

Tabs

Pages



Module Qt Mobility

Topics

- 1 Qt Components
- 2 Cheat Sheet
- 3 Questions
- 4 Lab

What is Qt Components?


Speed up Qt Quick development

Ready-made QML-based UI building blocks

Functional Symbian components




Setting up your environment




Create a Qt Quick Application project

Set the project up for Qt Simulator





Basic interface elements



First, import the Qt Components API

Window: the root component (handles transitions when rotating the screen)

StatusBar: display device's informations (connection, battery, time)

ToolBar: container for quick access to tasks

```
import QtQuick 1.0
import com.nokia.symbian 1.1

Window {
    id: root


    StatusBar {
        id: statusBar
        anchors.top: root.top
    }

    ToolBar {
        id: toolBar
        anchors.bottom: root.bottom
    }
}
```

See example: addon/module-010/examples/Basic/Basic.pro



Basic interface elements




ScrollDecorator: sets a temporary scrollbar to a flickable content while it is being dragged.

See video: addon/module-010/videos/Scroll.mov See example: addon/module-010/examples/Scroll/Scroll.pro



Style



Use platformStyle on properties (e.g. font.family: platformStyle.fontFamilyRegular)

fontFamilyRegular: default font family

fontSizeLarge: pixel size for a font fontSizeMedium / fontSizeSmall

graphicSizeLarge: size of a graphical object
(Image)
 graphicSizeMedium / graphicSizeSmall / graphicSizeTiny

paddingLarge: size of padding, in pixels paddingMedium / paddingSmall


colorNormalLight: default foreground color colorNormalMid / colorNormalDark / colorNormalLink

See the cheat sheet in the end of the module for more.

See example: addon/module-010/examples/Style/Style.pro




Text input





TextField can have placeholderText, integrated buttons and actions

Text area with multiline support.



TextArea can either be scrollable on fixed width and height or resize to fit all input characters


See videos: addon/module-010/videos/ClearableTextField.mov; TextArea.mov;

TextAreaNoHeight.mov

See example: addon/module-010/examples/Text/Text.pro



Buttons



Button: standard button with a text

ToolButton: different button compatible with icons

ButtonRow: arranges a set of buttons in a row

ButtonColumn: arranges a set of buttons in a column

RadioButton / CheckBox: button variations for specific purposes

ToolBarLayout: automatically arranges items on a toolbar

See the cheat sheet in the end of the module for more.

See video: addon/module-010/videos/Button.mov See example: addon/module-010/examples/Button/Button.pro



Menu



The Component element defines a QML component within the document, rather than a separate QML file

```
Component {
    id: menuComponent
    Menu {
        content: MenuLayout {
            MenuItem {
                text: "Menu Item"
        }
        MenuItem {
                text: "Quit"
                onClicked: Qt.quit()
        }
    }
}
```


The Menu component is hidden by default, therefore, you'll need to call it in an 'open' function.

MenuLayout automatically arranges the items in a Menu

See video: addon/module-010/videos/Menu.mov See example: addon/module-010/examples/Menu/Menu.pro



Dialog boxes



CommonDialog and QueryDialog are variations of Dialog with subtle differences

CommonDialog: Dialog with support to title text

Query Dialog: Common Dialog with support to icon, accept and reject buttons, and message


Selection Dialog: Can work together with Selection ListItem, showing the current value

ContextMenu: Menu meets Dialog

See video: addon/module-010/videos/Dialog.mov See example: addon/module-010/examples/Dialog/Dialog.pro



Tabs



TabBar: themeable background for TabBarLayout

TabBarLayout: positioner for the tab buttons

TabButton: has an image or label and can be clicked to activate a tab

TabGroup: set of pages for a tabbed interface

See video: addon/module-010/videos/Tab.mov See example: addon/module-010/examples/Tab/Tab.pro



Pages

Page 1 Page 2

Page: defines one screen of user interface content

PageStack: defines a container for pages and a stack-based navigation model

See video: addon/module-010/videos/Pages.mov See example: addon/module-010/examples/Pages/Pages.pro Module Qt Components


Topics

- 1 Qt Components
- 2 Cheat Sheet
- 3 Questions
- 4 Lab

Window

The root component which handles transitions when rotating screen, maintaining a full screen view.

StatusBar



Display the device's informations.

```
Ex.: Window {
    id: root


StatusBar {
    id: statusBar
    anchors.top: root.top
    }
}
```

ScrollDecorator

Adds a visual indicator to a Flickable element to show the size relationship between the visible and the complete contents.

```
Ex.: ListView {
    id: listView
    anchors.fill: parent
    focus: true
    clip: true
    model: listModel
    delegate: listDelegate
}

ScrollDecorator {
    id: scrollDecorator
    flickableItem: listView
}
```





Style

Symbian platform specific style parameters for fonts, colors and layouts. Use platformStyle property.

```
fontSizeLarge: pixel size for a large font (also: fontSizeMedium / fontSizeSmall)
graphicSizeLarge: size of a large graphical object (also: graphicSizeMedium / graphicSizeSmall /
graphicSizeTiny)
paddingLarge: size of a large padding in pixels (also: paddingMedium / paddingSmall)
borderSizeMedium: size for medium size border parts of a BorderImage, in pixels
colorNormalLight: default light foreground color (also: colorNormalMid / colorNormalDark / colorNormalLink)
colorPressed: foreground color for the pressed state (also: colorChecked / colorHighlighted)
colorDisabledLight: light foreground color for the disabled state (also: colorDisabledMid / colorDisabledDark)
colorTextSelection: background color for a selected item
```

```
Ex.: Text {
    font.family: platformStyle.fontFamilyRegular
    font.pixelSize: platformStyle.fontSizeMedium
}
```



Style

Image sources in the location "image://theme/".

- qtg_graf_popup_close_normal
- qtg_graf_search_indicator
- qtg_graf_slider_decrement_normal
- qtg_graf_slider_decrement_pressed
- qtg_graf_slider_increment_normal
- qtg_graf_textfield_add_normal
 qtg_graf_textfield_clear_normal
 qtg_graf_textfield_clear_pressed

- qtg_graf_popup_close_pressed
- qtg_graf_slider_increment_pressed
- qtg_graf_textfield_add_pressed



Style

ToolButton icons.

- toolbar-add
- in toolbar-delete
- ntoolbar-home
- toolbar-mediacontrol-backwards
- **Horward**
- toolbar-mediacontrol-pause
- > toolbar-mediacontrol-stop
- toolbar-next
- toolbar-refresh toolbar-settings

- ← toolbar-back
- toolbar-dialer
- **=** toolbar-list
- toolbar-mediacontrol-
- toolbar-mediacontrol-play
- **✓** toolbar-menu
- **Q** toolbar-previous
- toolbar-search
 toolbar-share

```
Ex.: ToolButton {
    iconSource: "toolbar-home"
}
```



TextField / TextArea

TextField and TextArea accept key inputs. TextArea is a multiline editor that resizes vertically to fit all characters.

font: font information for the text placeholderText: text shown before the user enters any text readOnly: if set to true, the field can't be edited, only viewed text: already entered text

Placeholder Text

Text area with multiline support.

```
TextArea {
    width: parent.width —

height: platformStyle.graphicSizeLarge
    placeholderText: "I accept many

readOnly: true

text: "You cannot change me"
 }
```



Button

checkable: if true, it becomes a toggle button with two states, 'on' and 'off'

checked: if true, it is toggled 'on'

font: font information for the text

text: the button label

This button is already checked

```
Ex.:

Button {
    width: parent.width - platformStyle.paddingLarge
    anchors.horizontalCenter: parent.horizontalCenter
    font {
        family: fontFamilyRegular
        pixelSize: fontSizeMedium
    }
    checkable: true
    checked: true
    text: "This button is already checked"
}
```

See video: addon/module-010/videos/CS_Button.mov



ToolButton

Different button, compatible with icons.

checkable: if true, it becomes a toggle button with two states, 'on' and 'off'

checked: if true, it is toggled 'on'

checked con Source: icon source for the checked state

enabled: if false, the button is disabled


flat: if true, it has a flat look

iconSource: icon source for the normal state

pressed con Source: icon source for the pressed state

text: the button label

Ex.: ToolButton {
 width: parent.width – platformStyle.paddingLarge
 anchors.horizontalCenter: parent.horizontalCenter
 iconSource: "toolbar-home"
 text: "Tool Button"
}





ButtonRow / ButtonColumn

Button positioners.

checkedButton: defines which button is checked

exclusive: if true, only one button at a time is toggled

```
Ex.: ButtonRow {
    width: parent.width - platformStyle.paddingLarge
    anchors.horizontalCenter: parent.horizontalCenter
    checkedButton: b2
    exclusive: true

Button { text: "One" }
    Button { id: b2; text: "Two" }
    Button { text: "Three" }
}
```



One Two Three




RadioButton / CheckBox

Button variations for specific purposes.

checked: if true, it is toggled 'on'

text: text shown beside the button

platformExclusiveGroup: exclusive group the RadioButton belongs to (can be replaced with ButtonRow or ButtonColumn)



```
Choose this...
...and this.
```

```
Ex.: CheckableGroup { id: group }
Row {
    RadioButton {
        text: "Choose this..."
        platformExclusiveGroup: group
    }
    RadioButton {
        text: "...or this."
        platformExclusiveGroup: group
    }
}
```

```
ButtonColumn {
    spacing: 10
    exclusive: false

CheckBox { text: "Choose this..." }
CheckBox {
    text: "...and this."
        checked: true
    }
}
```



ToolBar



Container for quick access to common tasks

tools: the tools that make up the content of the toolbar

transition: type of transition (set / push / pop / replace)

ToolBarLayout

Automatically arranges items on the ToolBar

backButton: if set to 'false', the leftmost space will be empty




Menu / ContextMenu

Provides a list of options the user can select from. ContextMenu opens in a popup dialog.

content: where you call for the content

MenuLayout

Automatically arranges the Menultems in a Menu






Dialog

Popup dialogs that float above the top layer of the application view

title: items for the title area of the dialog

content: items for the content area of the dialog

buttons: items for the buttons area of the dialog



```
Ex.: Dialog {
    title: Text {
        anchors { verticalCenter: parent.verticalCenter; left: parent.left; leftMargin: 10 }
        text: "Dialog"
        font { family: platformStyle.fontFamilyRegular; pixelSize: platformStyle.fontSizeLarge }
        color: platformStyle.colorNormalLink
    }
    buttons: ToolBar {
        tools: Row {
            ToolButton { text: "Ok" }
            ToolButton { text: "Cancel" }
        }
    }
    content: Text {
        text: "This is the content"
        color: platformStyle.colorNormalLight
        font.pixelSize: 16
    }
}
```




CommonDialog

Dialog with predefined layout for the title

titleText: string for predefined title layout

```
Ex.:
          CommonDialog {
            titleText: "Common Dialog"
            buttons: ToolBar {
               width: parent.width
               tools: Row {
                 anchors.center: parent
                 spacing: platformStyle.paddingMedium
                  ToolButton { text: "Ok" }
                 ToolButton { text: "Cancel" }
            content: Text {
               text: "This is the content"
               color: platformStyle.colorNormalLight
               font.pixelSize: 16
               anchor.fill: parent
               horizontalAlignment: Text.AlignHCenter
               verticalAlignment: Text.AlignVCenter
```





QueryDialog

CommonDialog with predefined layout for the icon, accept and

reject buttons, and content message.

icon: predefined icon layout, beside the title message: predefined content message layout acceptButtonText: predefined button layout (left) rejectButtonText: predefined button layout (right)

Query Dialog

Lorem ipsum dolor sit amet, consectetur adipisici elit,sed eiusmod tempor incidunt ut labore et dolore magna aliqua. Ut enim ad minim veniam, quis nostrud exercitation ullamco laborisnisi ut aliquid ex ea commodi consequat. Quis aute iure reprehenderitin voluptate velit esse cillum dolore eu fugiat nulla pariatur. Excepteur sint obcaecat cupiditat non proident, sunt in culpa quiofficia deserunt mollit anim id est laborum. Ut enim ad minim veniam, quis nostrud exercitation ullamco

0k


Cancel



SelectionDialog

Provides a list of options the user can choose from

```
titleText: predefined title layout
selected Index: selected option
model: options
         SelectionDialog {
Ex.:
            titleText: "Select"
            selectedIndex: 2
            model: ListModel {
               ListElement { name: "One" }
               ListElement { name: "Two" }
               ListElement { name: "Three" }
               ListElement { name: "Four" }
               ListElement { name: "Five" }
               ListElement { name: "Six" }
               ListElement { name: "Seven" }
               ListElement { name: "Eight" }
               ListElement { name: "Nine" }
```





TabBarLayout



Positioner for Tab Buttons

TabBar



Functions the same way as TabBarLayout, but is themed in a Symbian device style



TabButton

Has an image or label and can be clicked to activate a tab


checked: if button corresponds to the activated tab

iconSource: image shown on the button

tab: indicates the tab content (child of TabGroup) that is activated when the TabButton is clicked

text: text to be displayed on the button

```
Ex.: TabButton {
    tab: tab1Content
    text: "Home"
    iconSource: "toolbar-home"
    checked: false
}
```





TabGroup

A set of pages for a tabbed interface

```
TabGroup {
Ex.:
             anchors: { top: toolBar.bottom; bottom: tabBar.top; left: parent.left; right: parent.right }
             Button {
               id: tab1content
               text: "tab1"
             Text {
               id: tab2content
               text: "tab2"
               horizontalAlignment: "AlignHCenter"
               verticalAlignment: "AlignVCenter"
               color: platformStyle.colorNormalLight
             Page {
               id: tab3content
               CheckBox {
                  anchors.centerIn: parent
                  text: "tab3"
```



Page

Defines one screen of the interface content

tools: defines the tools for the page

```
Ex.: Page {
    Text {
        id: label anchors.centerIn: parent text: "Page 1" color: "white"
    }

    tools: ToolBarLayout {
        ToolButton {
            flat: true iconSource: "toolbar-back"
        }
        ToolButton {
            flat: true text: "Page 2"
        }
    }
}
```



PageStack

Defines a container for pages and a stack-based navigation model

currentPage: the page in the stack that is currently visible

toolBar: toolbar container for the tools associated with each page (if toolbar is null, no tools are shown to the user even if a page has tools)

```
Ex.: PageStack {
    id: pageStack
    anchors { left: root.left; top: root.top; right: root.right; bottom: mainToolBar.top }
    toolBar: mainToolBar
}

ToolBar {
    id: mainToolBar
    anchor.bottom: parent.bottom
}
```



Module Qt Components

Topics

- 1 Qt Components
- 2 Cheat Sheet
- 3 Questions
- 4 Lab



Questions

How can you retrieve Symbian platform specific styles?

How does Menu work?

What's the difference between TabBar and TabBarLayout?

What's the difference between Page and Component?

When would you use QueryDialog, CommonDialog and Dialog?




Module Qt Components

Topics

- 1 Qt Components
- 2 Cheat Sheet
- 3 Questions
- 4 Lab

Lab

Build a 3-tabbed app using the provided cheat sheet as reference



See video: addon/module-010/videos/lab.mov

See lab: addon/module-010/labs/lab-10



(c) 2011 Nokia Corporation and its Subsidiary(-ies).

The enclosed Qt Training Materials are provided under the CreativeCommons Attribution ShareAlike 2.5 License Agreement.



The full license text is available here: http://creativecommons.org/licenses/by-sa/2.5/legalcode

Nokia, Qt and the Nokia and Qt logos are the registered trademarks of Nokia Corporation in Finland and other countries worldwide.

